


MC162 RS232 界面板



特性

- 隔離式 RS232 界面板.

注: 只能配合某些型號的控制板使用

使用說明書

裝置代號: 162

IMPORTANT

Although the information contained herein has been carefully verified, **NEWELL TECHNOLOGIES LIMITED** assumes no responsibility for any errors that may occur, for any damage to property or persons resulting from improper use of this manual or from the related software. **NEWELL TECHNOLOGIES LIMITED** products are not authorized for use as components in medical, life support or military devices. No patent licenses are implied. **NEWELL TECHNOLOGIES LIMITED** reserves the right to change the features and specifications without notice at any time.

Newell Technologies Ltd.

接口說明

- J1 接到控制板
- J2 接 RS232 數據線

技術支援

您可通過下面途徑取得技術支援服務及新的產品信息

電話: (852)-27827895

傳真: (852)-27825650

電子郵箱: support@hkits.com

<http://www.easy-controls.com>